

Running Fluidity and Visualising the Results

Jon Hill¹

1 - Dept of Earth Science and Engineering, Imperial College London

Outline

Running

Output

- Filetypes and tools

- The stat file

- Paraview

- Python

Parallel

- Running

- Post-running

Outline

Running

Output

- Filetypes and tools

- The stat file

- Paraview

- Python

Parallel

- Running

- Post-running

Running Fluidity

./fluidity

Running Fluidity

```
Revision: fluidity/4.1
Compile date: Nov 20 2012 10:16:12
OpenMP Support no
Adaptivity support yes
...
FEMDEM support no
Hyperlight support no
```

Usage: fluidity [options ...] [simulation-file]

Options:

-h, --help

Help! Prints this message.

-l, --log

Create log file **for** each process (useful **for** non-interactive testing).

-v <level>, --verbose

Verbose output to stdout, default level 0

-p, --profile

Print profiling data at end of run

This provides aggregated elapsed time **for** coarse-level computation

(Turned on automatically **if** verbosity is at level 2 or above)

-V, --version

Version

Running Fluidity

```
./fluidity my.flml  
./fluidity -l my.flml  
./fluidity -l -v3 my.flml
```

Outline

Running

Output

- Filetypes and tools

- The stat file

- Paraview

- Python

Parallel

- Running

- Post-running

Filetypes

There are **two** main filetypes:

- ▶ .stat file
- ▶ Unstructured VTK file (.vtu or .pvtu)

You may also have log files:


- ▶ fluidity.log.*
- ▶ fluidity.err.*

Tools


- ▶ Statplot
- ▶ Paraview
- ▶ Python
 - ▶ vtktools
 - ▶ fluidity.statparser

The stat file


- ▶ Bespoke data file type
- ▶ Various tools to read and process these data
- ▶ Either ASCII or binary

Header

Data
<pre> 0101010110101010101010101010001010 1010101010101010110100101001001011 0101010101010101010111000101010001 0010101010010101010100101010101000 </pre> <p>or</p> <pre> 0.4800000000000000E+003 0.4800000000000000E+003 0.1902799999999999E +002 1.683 6000 2480 0.1892308800000000E+008 0.0000000000000000E+000 0.2305111600000000E +008 0.2683280000000000E+007 0.0000000000000000E+000 0.2683280000000000E +007 0.1464480000000000E+007 0.0000000000000000E+000 0.2052736000000000E +007 0.2532840000000000E+007 0.0000000000000000E+000 0.3684840000000000E +007 0.2168784000000000E+007 0.0000000000000000E+000 0.3896784000000000E </pre>

Statplot



Statplot



Statplot keys

- ▶ s - scatter plot
- ▶ l - line plot
- ▶ r - refresh data
- ▶ R - refresh data, but keep current bounds
- ▶ x - switch x-axis from linear to log or vice versa
- ▶ y - switch y-axis from linear to log or vice versa
- ▶ q - quit (note: **no warnings!**)

Statplot example


Open the stat file at from your advection problem

Things to try:


- ▶ Switch between scatter plot and line plot views
- ▶ Change the graph to show the number of elements through the run
- ▶ Plot velocity magnitude minimum against velocity magnitude maximum
- ▶ Zoom in and save a small part of the plot to file

Paraview

Open-source scientific visualisation software from KitView




Paraview: main window




Paraview: main window




Paraview: main window




Paraview: main window




Paraview



Paraview



Paraview



Paraview

- ▶ Right click: Zoom-in and out
- ▶ Left-click: rotate
- ▶ Middle-button: move
- ▶ Zoom in and save a small part of the plot to file

Animations

1. File → Save Animation
2. Set up parameters
3. Click “Save Animation”
4. create folder and give filename

Animations

From PNGs produce movie via mencoder:

```
export opt=
"vbitrate=4705000:mbd=2:keyint=132:vqblur=1.0:cmp=2:subcmp=2:dia=2
mencoder -ovc lavc -lavcopts vcodec=msmpeg4v2:vpas=1:$opt
    -mf type=png:fps=10 -nosound -o /dev/null mf://*.png
mencoder -ovc lavc -lavcopts vcodec=msmpeg4v2:vpas=2:$opt
    -mf type=png:fps=10 -nosound -o output.avi mf://*.png
```

Script in fluidity/bin/encode

Python tools

- ▶ vtktools - read vtu files
- ▶ statparser - read stat files

Useful python modules

- ▶ numpy - numerical package, including arrays
- ▶ stats - linear regression, etc
- ▶ matplotlib - plotting 2- and 3-D

Python VTU

```
#!/usr/bin/env python
import vtktools
x0 = 0
y0 = 0

for file in filelist:
    num = int(file.split(".vtu")[0].split('_')[-1])
    u=vtktools.vtu(file)
    time = u.GetScalarField('Time')
    tt = time[0]
    den = u.GetScalarField('Density')
    p = u.GetLocations()
    xyz_data = []
    for i in range(0,len(den)):
        if (x0-0.1<p[i,0]<x0+0.1 and y0-0.1<p[i,1]<y0+0.1):
            xyz_data.append((p[i,0],p[i,1],-p[i,2],1024*den[i]))
```

Examples

```
#!/usr/bin/env python
from fluidity_tools import stat_parser

# load in statfile to get element info
stat=stat_parser( direc + '/' + stat_file )

elements = stat['CoordinateMesh']['elements']
nodes = stat['CoordinateMesh']['nodes']

maxVelocity = stat["Fluid"]["Velocity%magnitude"]["max"]
```


Examples

```
#!/usr/bin/env python
from pylab import *

figure(x)
title(warray[x]+"_water_gauge_at_"+str(xarray[x])+"m")
xlabel('Time_(s)')
ylabel('Water_Depth_(m)')
experiment = numpy.load(warray[x]+".npz")
plot(experiment[:,0],
      experiment[:,1],marker='o',markerfacecolor='white',markersize=6,
      markeredgecolor='black',linestyle="None")

time = results[:,1]
plot(time, results[:,2+x],color='black',linestyle="dashed")
axis([0.0, 2.5, 0.0, 0.5])
legend(("Experiment", "Fluidity"), loc="upper_left")
savefig("water_gauge_"+warray[x]+".pdf")
```

Examples



Outline

Running

Output

Filetypes and tools

The stat file

Paraview

Python

Parallel

Running

Post-running


FLML

No changes required!


[Optional]

- ▶ Remove fields from stat file
- ▶ Remove some fields from VTU


Decompose mesh




Decompose mesh




Decompose mesh




Decompose mesh



Decompose mesh



Decompose mesh



flrecomp

```
mpiexec -n 8 flrecomp -i 2 -o 8 InputFLML OutputFLML
```

Will decompose mesh from 2 to 8.

```
mpiexec -n 8 flrecomp -i 8 -o 2 InputFLML OutputFLML
```

Will decompose mesh from 8 to 2.

Both need running on 8 processors

Note: Do not add .flml to files, e.g. InputFLML not InputFLML.flml

Note: Change of FLML filename to run

Local systems

```
mpiexec -n 8 ../../bin/fluidity  
my_flredecompd.flml
```

Visualisation

No different from serial - except .pvtu files, not .vtu

Log files (if used) will be one per processor.